

UDC1200 & UDC1700 Universal Digital Controllers Series Micro-Pro

Specifications

51-52-03-35 June 2011



Overview

The UDC1200 & UDC1700 are microprocessor-based 1/16 DIN and 1/8 DIN controllers, which combine a high degree of functionality and reliability at low cost.

They are fully dedicated to monitor and control temperatures, pressures and levels in a wide range of applications such as environmental chambers, furnaces, ovens, packaging machines and other applications in plastics and the food and beverage industries. The large and easy-to-read dual 4-digit display and tactile keypad make the UDC1200 and UDC1700 easy to configure and use. Their outstanding flexibility enables you to configure any unit for any application and change it if required.

For the thousands of satisfied UDC1000/1500 users, the UDC1200/1700 controllers are downward compatible to existing UDC1000/1500 applications and installations.

Features

Dual display

Two 4-digit displays with 7 LED segments, each configurable for:

- PV and SP (non adjustable)
- PV and SP (adjustable)
- PV and Ramping SP
- PV only


Easier to configure

Two different configuration levels (Configuration mode and set-up mode) provide easy access to parameters. A 4-digit security code prevents unauthorized changes.

Moisture resistant front-face

Meets NEMA 3 / IP65 front-face protection against dust and water.







UDC1200

Universal input

Accept seven different types of thermocouples, RTDs, current and voltage linear inputs. All inputs are configurable as standard.

Universal power supply

The UDC1200 and UDC1700 can operate on any line voltage from 90 Vac to 264 Vac at 50/60 Hz. A 24/48 Vac/dc model is available as an option.

Easy upgrade

All the option boards are jumper free and detected automatically by the instrument.

Easy output selection

All the outputs (including the control output) of the instrument can be changed to meet the exact customer's needs.

Alarm strategy

Two soft alarms for PV, deviation high/low/absolute. A special loop alarm is also provided to detect faults in the control loop by continuously analyzing the PV response to the control output. Alarm inhibit is available on power up and setpoint switching.

Manual/Automatic mode

Manual control (via bumpless transfer) is enabled by simply pressing the front-face AUTO/MAN key. The "SET" LED flashes and the output power is displayed on the lower display. Output can be adjusted with the upper and lower keys.

Pre-tuning and self-tuning strategy

Pre-tuning is used to set up the PID parameters close to the optimum values, which the self-tuning algorithm uses to subsequently optimize the tuning parameters.

Limit controller

Packaged in 1/16 DIN, the UDC1200 limit controller is designed to provide a safety shut-off and optional alarm for use in a wide variety of applications.

Up to three outputs

The UDC1200 and UDC1700 provide up to three outputs for time and current proportioning, duplex mode (heat/cool), PV or SP retransmission, and alarms.

Setpoint ramp

The current setpoint can ramp to a new-targeted setpoint by way of a user defined ramp rate.

Dual setpoint

Dual setpoint option is available on the UDC1200 and UDC1700. The current setpoint is selected by a digital input. This option is exclusive with UDC1200 limit model remote alarm reset.

Communication

An optional RS485 communications interface is available on the UDC1200 and UDC1700. It provides a link for up to 32 units and a host computer through ASCII or Modbus RTU protocol at up to 19200 baud.

Highly secure

A non-volatile memory based on EEPROM technology ensures data integrity during loss of power supply, with retention of more than 100 years. A 4-digit security code prevents unauthorized or accidental change.



Upper display: 4 characters dedicated to show the PV. In configuration mode, it shows the parameter value or selection

Lower display: 4 characters dedicated in normal operation mode to display the SP. In configuration mode, it displays the parameter name.



UDC1200



Selects manual or automatic mode. Becomes « Reset » on UDC1200 Limit model.



Allows operator mode parameters to be scrolled. In combination with the «Upper» key, allows configuration mode or Setup mode to be entered.



Increases setpoint, output or configuration parameter values.



Decreases setpoint, output or configuration parameter values.

Optional Features

The following can be selected via the Model selection Guide (see page 8):

- RS485 ASCII communication
- RS485 Modbus RTU communication
- Digital Input
- Output 2
- Output 3
- Power Supply 24/48 Vac/dc

Physical Description

The UDC1200 controller is housed in a 110 mm (4.33 inches) deep case with a standard UDC gray bezel. It can be mounted in a 1/16 DIN panel cutout.

The UDC1700 controller is housed in a 100 mm (3.94 inches) deep case and can be mounted in a 1/8 DIN panel cutout. By using the pre-assembled mounting fixture delivered with the unit, you can easily and securely install the controller into the panel cutout. Modular plug-in construction allows rapid access and saves time. All inputs and outputs are connected on the rear terminal block by screws.

Operator Interface

Four display combinations are offered to the operator. The upper 4-digit 7-segment display is always dedicated to monitor the PV. The lower display can show:

- SETPOINT (read only)
- SETPOINT (adjustable)
- RAMPING setpoint (ramp mode)
- BLANK

Universal Inputs

All input types are available on any unit. Selection among the various types of inputs is made by prompt configuration. As soon as the Process Variable reaches the value of the input range limit, the controller displays a message. A sensor break indication is also provided. A configurable digital filter is available from 0.5 seconds to 100.0 seconds.

Outputs

Three types of outputs (RELAY, SSR driver or DC linear) are selectable for three outputs, through the model selection guide or by adding a plug-in module for outputs 1, 2 and 3.

Outputs Algorithm

The UDC1200 and UDC1700 are available with the following output algorithms:

• Time proportional:

ON/OFF or time proportional with electromechanical relay SPDT 2 A or SSR driver (open collector).

• Current proportional:

Supply directly proportional current or voltage signal to the final control elements which require 0-20 mA, 4 20 mA, 0-10 V or 0-5 V.

Time proportional duplex:

Three duplex modes can be selected, either ON/OFF duplex, time proportional duplex (heat/cool with two proportional bands, two cycle times and deadband) or TPSC.

Current proportional duplex:

In addition to the first current/voltage output, a second similar output with its own proportional band is provided.

• Current/Time or Time/Current duplex:

Provides a variation of traditional time or current duplex mode by mixing current and time proportioning together.

Control Algorithms

Four control algorithms can be set up through the configuration menu:

On/Off PID

■ PD + MR ■ TPSC

The TPSC (Three Position Step Control) control algorithm is dedicated to control valve positioning without slidewire feedback from the motor shaft.

Configuration

There are two levels of configuration. The SET-UP mode allows modification of current parameters such as tuning parameters, alarm values, setpoint limit, ramp enable, auto-manual mode enable and auto-pretune enable.

The CONFIGURATION mode is more oriented to unit personality: input selection, output 2 and 3 usage, alarm type, communication address and lockout code.

The operator mode screens are only selectable via the configuration software only. For instance, the alarm value screen can be moved from setup mode to normal operator mode if desired.

Control Mode

Manual or automatic mode with bumpless transfer is standard feature. In manual mode, the operator can directly control the output through the two front face keys (raise and lower keys). The output value is monitored on the lower display.

Alarms

Outputs 1, 2 and 3 can be used as alarms. Two electromechanical single pole double throw relays can activate external equipment when alarm setpoints are reached. An LED is also activated on the front-face. A direct or reverse acting alarm output can be configured. A logical combination of the two alarms: OR, AND or hysteresis (active when both alarms are active and inactive when both alarms are inactive) can be set which associates the two alarms status before energizing the relay. In order to detect a defective control loop, the controller can supply special loop alarm control by continually monitoring the PV response to output demand. A timer is automatically set up when any output is on saturation mode. When the timer reaches twice the reset time with no PV response, the loop alarm is activated. With this soft alarm there is no need for a heater circuit breaker, saving wiring time and costs.

Display

Dual, four-digit LED display with decimal point location configurable up to three places for linear ranges only.

Limit Controller

The UDC1200 1/16 DIN limit controller provides a latched relay output which is activated when the process parameters either exceed or fall bellow the desired value, providing a failsafe cut-off which has to be manually reset before the process can continue.

The UDC1200 limit controller can be configured to be either a "high limit" unit where the delay will de-energize when the PV is above the limit setpoint, or a "low limit", where the relay will drop out when the PV falls below the setpoint.

A LED indicator shows when limits have been exceeded, and when the relay is latched out.

The optional digital input allows a remote reset function.

Remote Setpoint Model

The UDC1700 1/8 DIN "R" model controller has a second input available that accepts either a linear or potentiometer input signal as a remote setpoint. The input signals accepted are field-configurable and are: 0-5 V, 1-5 V, 0-10 V, 2-10 V, 0-20 mA, 4-20 mA (factory set), 0-50 mV, 10-50 mV, 0 100 mV, or 0-2000 ohms. This allows the controller to act as a "slave" controller accepting a setpoint value from a 'master' device such as a PLC or setpoint-programming controller (such as the DCP50, DCP100, DCP300, or DCP550 series).

The UDC1700R also includes a standard digital input allowing remote switching between the local setpoint and the remote setpoint value. Also standard in this model is "fuzzy" autotune software that minimizes process variable overshoot when responding to a setpoint change.

PC Software

The UDC1200 & 1700 are supported with PC software allowing you to quickly configure your device using configuration wizards, or to perform diagnostics.

Specifications (Applies to both UDC1200 and UDC1700)

Technical data	
Accuracy	0.1 % of span ± 1 LSD
Temperature Stability	0.01 % of span per °C
Input Signal Failure	Fail-safe output value: Achieved when burnout is detected. Value depends on configuration. For thermocouple and mV input detected by any lead break: Upscale burnout For RTD: Burnout detected by any lead break Current or voltage input: Burnout set by open circuit detection
Input Impedance	Voltage impedance: 47 Kohms Current input: 4.7 ohms All others: 100 Mohms
Input Sampling Rate	Four samples per second
Input Filter	Digital filter configurable from front panel 0.0 (Off), from 0.5 seconds to 100.0 seconds in 0.5 seconds increment
Input Resolution	14 bits approximately, always four times better than display resolution
Input Isolation	Universal input isolated at 2500 V from all outputs except SSR and from power supply
Stray Rejection	Common mode rejection: > 120 dB at 50/60 Hz Serial mode rejection: > 500% of span at 50/60 Hz
Approvals	UL recognized to US & Canadian standards FM approval on the UDC1200 limit model Product design to meet CE MARK requirement
Control Output Type	Type available: Output 1/2/3: DC, Electromechanical relay, SSR drive (open collector) DC linear output: 0-20 mA, 4-20 mA, 0-5 V, 0-10 V Accuracy: ± 0.25 % (250 ohms for mA, 2 Kohms for voltage) Resolution: 80 bits in 250 ms (10 bits in 1 second typical > 10 bits in > 1 second) Load impedance: 500 ohms maximum for current output, 500 ohms minimum for voltage output Isolation: Isolated 2500 V from all other inputs and outputs Range selection method: Front panel code setting Temperature stability: 0.01 % / °C Electromechanical relay: SPDT contact Resistive load: 2 A at 120 V or 240 V Life time: > 500000 operations at rated voltage/current SSR drive/TTL: Drive capability: SSR > 10 Vdc into 250 ohms minimum Isolation: Not isolated from input and other SSR output
Alarms	Maximum number of alarms: 2 soft alarms setpoint + 1 loop alarm Alarm inhibit available on power up and setpoint switching Alarm output: Up to two relays or SSR output on outputs 2 and 3 Types: PV high or low, band, deviation high or low, loop Combination alarms: Logical "OR", "AND" or hysteresis of alarms available to individual hardware output

Loop Control	Automatic tuning type: Pre-tune and self-tune
	Proportional bands: 0 (inactive), 0.5 % to 999.9 % of input span with 0.1% increments.
	Two proportional bands available for duplex mode
	Reset: Off or from 1sec. to 99 min 59 sec.
	Rate: From 0 sec. to 99 min 59 sec.
	Manual reset: from 0 to 100 % of output (single output), from –100 % to 100 % of output (dual output)
	Deadband: ± 20 of PB1 + PB2
	ON/OFF hysteresis: 0.1% to 10.0 % of input span
	Auto/manual mode: Front key selectable with bumpless transfer between automatic and manual mode
	Cycle times: Up to two cycle times available for time duplex control
	Selection: 0.5, 1, 2, 4, 8, 16, 32, 64, 128, 256, or 512 seconds
	Setpoint ramp: From 1 to 9999 engineering units per hour
Retransmission Output	Any output can be selected to retransmit the process value or setpoint as a linear (current or voltage) output
Digital Input (optional)	On contact the digital input will switch between SP1/SP2 or Auto/Manual or DC100L Remote Reset
Communication Interface	RS485 – ASCII or Modbus RTU (selectable from the menu)
	Baud rate: 1200, 2400, 4800, 9600 or 19200 baud
	Link characteristics: 32 drops maximum, ASCII or Modbus protocols, two wires
Mounting	Plug-in with pre-assembled mounting fixture
Wiring Connection	Screw terminals on the rear of the case (combination head)
Power Consumption	4 W
Physical (UDC1200)	Weight: 210 grams maximum
	Height: 48 mm / 1.89 in
	Width: 48 mm / 1.89 in
	Depth: 110 mm / 4.33 in
	Cut out: 45 mm x 45 mm / 1.77 in x 1.77 in
Physical (UDC1700)	Weight: 250 grams maximum
	Height: 96 mm / 3.78 in
	Width: 48 mm / 1.89 in
	Depth: 100 mm / 3.94 in
	Cut out: 45 mm x 92 mm / 1.77 in x 3.62 in
Environmental	EMI Susceptibility: Designed to meet EN55101
	EMI Emission: Designed to meet EN55022
	Safety Considerations: Designed to comply with IEC1010-1as far as applicable
Front Panel Sealing	NEMA 3 / IP66

Input Actuations			
			Ranges
Thermocouple	types	°F	°C
(Fixed decimal)	R	32 – 3198	0 – 1759
,	s	32 – 3204	0 – 1762
	J	-328 – 2192	-200 – 1200
	J	-199.9 — 999.9	-128.8 – 537.7
	Т	-400 – 752	-250 – 400
	Т	-199.9 – 752	-128.8 – 400
	K	-400 – 2503	-240- 1373
	K	-128.8 – 537.7	-199.9 – 999.9
	L	32 – 1403	0 – 762
	L	32 – 999.9	0 – 537.7
В		211 – 3315	100 – 1824
	С	32 – 4208	0 – 2320
	N	32 – 2551	0 – 1399
RTD: (3 wires connection))		
PT100 (IEC) $\alpha = 0.00385$		-328 – 1472	-199 – 800
(Fixed decimal)		-199.9 – 999.9	-128.8 – 537.7
DC linear:		10 – 50 mV	0 – 50 mV
		4 – 20 mA	0 – 20 mA
		1 – 5 V	0 – 5 V
		2 – 10 V	0 – 10 V

Operating Conditions			
	Reference Conditions	Operative Limits	Transportation and Storage
Ambient Temperature	20 °C ± 2 °C (68 °F ± 4 °F)	0 °C to 55 °C (32 °F to 131 °F)	–20 °C to 80 °C (–4 °F to 176 °F)
Relative Humidity	60-70 %	20-95 % non -condensing	
Voltage	90-264 Vac ± 1 %	90-264 Vac	
Frequency	50 Hz	50-60 Hz	
Source Resistance	< 10 ohms for thermocouple	1000 ohms maximum for thermocouple	
Lead resistance for RTD	< 0.1 ohm/lead (PT100)	50 ohms per lead maximum balanced	

Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

Asia Pacific Global **Technical Support**

Field Instruments Phone: +65 6580 3156 Fax: +65 6445-3033

Honeywell Limited Phone: +(61) 7-3846 1255 FAX: +(61) 7-3840 6481 Toll Free 1300-36-39-36 Toll Free Fax: 1300-36-04-70

China - PRC - Beijing

Honeywell China Inc. Phone: +(86-10) 8458-

Fax: +(86-10) 8458-4650

China - PRC - Shanghai Honeywell China Inc.

Phone: (86-21) 5257-4568 Fax: (86-21) 6237-2826

China - PRC - Chengdu Honeywell China Inc.

Phone: +(86-28) 6613-5078

Fax: +(86-28) 8678-7061

China - PRC - Xi'an Honeywell China Ltd -

Xi'an. Phone: +(86-29) 8833-7490

Fax: +(86-29) 8833-7489

China - PRC - Shenzhen-

Honeywell China Inc. Phone: +(86) 755-2518-1226

Fax: +(86) 755-2518-1221

Indonesia

PT Honeywell Indonesia Phone: +(62) 21-535-8833 FAX: +(62) 21-5367 1008

Honeywell Automation

India Ltd. Honeywell Ltd. Phone:+(91) 6603-9400 Fax: +(91) 6603-9600

Japan

Honeywell Inc. Phone: +(81) 3 6730 7197 Fax: +(81) 3 6730 7228

Malaysia

Honeywell Engineering Sdn Bhd

Phone: +(603) 7958-4788 Fax: +(603) 7958-8922

New Zealand

Honeywell Limited Phone: +(64-9) 623-5050 Fax: +(64-9) 623-5060 Toll Free (0800) 202-088

Singapore

Honeywell Pte Ltd. Phone: +(65) 6580 3278 Fax: +(65) 6445-3033

South Korea

Honeywell Korea Co Ltd Phone: +(822) 799 6114 Fax: +(822) 792 9015

Thailand

Honeywell Systems (Thailand) Ltd. Phone: +(662) 693-3099 FAX: +(662) 693-3089

Taiwan R.O.C.

Honeywell Taiwan Ltd. Phone: +(886-2) 2245-1000

FAX: +(886-2) 2245-3243

SE Asia Countries

see Honeywell Pte Ltd (Singapore) for: Philippines, Pakistan, Cambodia, Guam, Laos, Myanmar, Vietnam, East Timor

SE Asia Countries

see Honeywell Automation India Ltd for: Bangladesh Nepal Sri Lanka

EUROPE

Austria

Honeywell Austria GmbH Phone: +43 (316)400123 FAX: +43 (316)40017

Belgium

Honeywell SA/NV Phone:+32 (0)2728 24 07 FAX: +32 (0)2728 22 45

Bulgaria

Honeywell EOOD Phone: +(359) 2 40 20 900

FAX: +(359) 2 40 20 990

Czech Republic

Honeywell spol. s.r.o. Phone:+420 242 442 232 FAX: +420 242 442 131

Denmark

Honeywell A/S Phone: +(45) 39 55 55 55 FAX: +(45) 39 55 55 58

Finland

Honeywell OY Phone: +358 (0)20752 2753 FAX: +358 (0) 20752 2751

France

Honeywell SA Phone: +33 (0)1 60198075 FAX: +33 (0)1 60198201

Honeywell AG Phone: +49 (69)8064-299 FAX: +49 (69)806497336

Hungary

Honeywell Kft. Phone: +36-1-451 4300 FAX: +36-1-451 4343

Italy

Honeywell S.p.A. Phone:+390292146307 FAX: +39 0292146377

The Netherlands

Honeywell B.V. Phone: +31 (0) 20 5656200 FAX: +31 (0) 20 5656210

Norway

Honeywell A/S Phone: (45) 39 55 55 55

Honeywell Sp. zo.o Phone: +48-22-6060900 FAX: +48-22-6060901

Portugal

Honeywell Portugal Lda Phone: +351 21 424 5000 FAX: +351 21 424 50 99

Romania

Honeywell Bucharest Phone: +40 (0) 21 2316437 FAX: +40 (0) 21 2316439

Russian Federation (RF),

Honeywell Field Solutions Kievskaya str., 7, Moscow 121059, Russia Phone +7 (495) 796 98 60 +7 (495) 797 99 64

Slovak Republic

Honeywell s.r.o. Phone: +421-2-58247 410 FAX: +421-2-58247 415

Spain

Honeywell S.A. Phone: +34 (0)91313 61 00 FAX: +34 (0)91313 61 30

Sweden

Honeywell AB Phone: +(46) 8 775 55 00 FAX: +(46) 8 775 56 00

Switzerland

Honeywell AG Phone: +41 18552448 FAX: +(41) 1 855 24 45

Honeywell Turkey A.S. Phone: +90 216 578 71 00 FAX: +90 216 575 66 35

Ukraine

Honeywell Tel: +380-44-201 44 74 Fax: +380-44-201-44-75

United Kingdom

Honeywell Control Systems Ltd.

Phone: +44 (0)1344 655251 FAX: +44 (0) 1344 655554

MIDDLE EAST

Abu Dhabi U A E

Middle East Headquarters Honeywell Middle East Ltd. Phone: +971 2 4041246 FAX: +971 2 4432536

Sultanate of Oman

Honeywell & Co Oman LLC Phone: +968 24 701153/ Ext.33 FAX +968 24 787351

Saudia Arabia

Honeywell Turki Arabia Ltd Jubail Office Phone: +966-3-341-0140 Fax: +966-3-341-0216 Honeywell - ATCO

Dammam Office Phone: 0096638304584 Fax: 0096638338059

Kuwait

1714

Honeywell Kuwait KSC Phone: +965 242 1327 to 30 Fax: +965 242 8315 And Phone: +965 326 2934/1821Fax: +965 326

AFRICA

Mediterranean & African Distributors

Honeywell SpA Phone: +39 (02) 250 10 604 FAX: +39 (02) 250 10 659

South Africa (Republic of) and sub saharan

Honeywell Southern Africa Honeywell S.A. Pty. Ltd. Phone: +27 11 6958000 FAX +27 118051504

NORTH AMERICA

Canada

Honeywell LTD Phone: 1-800-737-3360 FAX: 1-800-565-4130

USA

Honeywell Process Solutions, Phone: 1-800-423-9883 Or 1-800-343-0228 Email: <u>ask-</u> ssc@honeywell.com

SOUTH AMERICA

Argentina

Honeywell S.A.I.C. Phone: +(54-11) 4383-3637 FAX: +(54-11) 4325-6470

Honeywell do Brasil & Cia Phone: +(55-11) 7266-1900 FAX: +(55-11) 7266-1905

Honeywell Chile, S.A. Phone: +(56-2) 233-0688 FAX: +(56-2) 231-6679

Mexico

Honeywell S.A. de C.V. Phone: +(52) 55 5259-1966 FAX: +(52) 55 5570-2985

Puerto Rico

Honeywell Inc. Phone: +(809) 792-7075 FAX: +(809) 792-0053

Trinidad

Honeywell Inc. Phone: +(868) 624-3964 FAX: +(868) 624-3969

Venezuela

Honeywell CA Phone: +(58-2) 238-0211 FAX: +(58-2) 238-3391

Model Selection Guides are subject to change and are inserted into the specifications as guidance only. Prior to specifying or ordering a model check for the latest revision Model Selection Guides which are published at: http://hpsweb.honeywell.com/Cultures/en-US/Products/Instrumentation/ProductModelSelectionGuides/default.htm

Model Selection Guide

HARAV		\cap											51	-51-	16U	-78			Π				
Honey	AA												Iss	sue	13								
			\Box				I	\perp				\perp	Pa	ige 1	of 3	3							
			_		_	_	╧		+		-	+											
UDC120)O I	ΜI	C	R	O.	·P	R	O						10	de)	Se	ele	Ct	İΟ	n	G	uide
Univers	al	Di	gi	ita	al	C	0	nt	ro	lle	er												
			Ĭ				I	\perp															
	+	\vdash	\dashv				+	+	+		+	+	+		\dashv	+		+	+				
Instructions							T					T											
Select the desi	red ke	ey nu	mbe	er.	The	arro	w to	o the	rigl	nt ma	irks	he	seled	tion	s av	ailab	le.		Т				
Make one sele	ction	each	fror	n T	able	s I th	ıroı	Jah '	√III u	sina	the	colu	ımn l	oelo	w the	e pro	per	arro	w.				
I I I I I I I I I I I I I I I I I I I								.g	T							, p. (, p 0.		Ï				
Key Number	1		II		Ш	I۱	,	V	T	۷I	٧	II	VII	ı	\neg	\top		\top	T				
DC	-[-] - [_	- [-1	- [-	1	- [-	Ţ -		- [-] -	- [_										
KEY NUMBER							T					Ť		80	ecti	on	_	vaila	hili	hv			
KET NOWIBER	_	Des	crip	otio	n		+	+	+		+	+	+	36	CUI	-		Valle		Ly .			
1/16 DIN Controll	er:	RTI	D or	Lir	near	mV						\top		DC	120	11 ,	F						
48x48mm		The	ermo	осо	uple		Ť		Т					DC	120	2	↓		T				
Input Type		Line	ear	mΑ			Т					Т		DC	120	3		↓					
(Field Selectable)					tage		Т		Т			Т		DC	120	4			↓				
		Lim	it C	ont	rolle	r - Fl	MΑ	ppro	ved					DC	120	L				₩			
		TPS	SC (Con	trolle	er (T	her	mod	oup	le Fa	ctor	/Se	t)	DC	120	Т					↓		
TABLEI	-	+	\dashv	-	-	+	+	+	+		+	+	-		\dashv	+	-	+	+	-			
Output 1	_	Rel	21/	-	-	+	+	+	+		+	+	+		1	٦,		٠.	١.				
Output 1			R Di	rive	r	_	+	+	+		+	+	-		2				•	1	•		
	_				10 V	olts.	+	+	+		+	+	+		3	١,		_	١.	\vdash			
	_				20 n	-	+		+		-		+		4	١,			•		•		
					5 Vo		+		+		+	+			5	١,			•		•		
					20m/		$^{+}$		+		\pm	+			7	٦,			•		•		
							T																
TABLE II							T								\neg								
Output 2		Nor	ne				Т	\top	Т		\neg	Т		П	0	٦,	•	1•	•	•			
		Rel	ay												1	•		•	•	•	•		
		SSF	R Di	rive	r		Т					Т			2	١.		•	•	•	•		
		Line	ear:	0 -	10 V	olts/									3	•	•			•	•		
		Line	ear:	0 -	20 n	na	Т								4	•	•	•	•	•	•		
					5 Vo										5	•	•	•	•	•	•		
					20m/	•	\perp								7	_ '	•	•	•	•	•		
		Dua	al R	ela	y Boa	ard	1	\perp							9				_	_	•	Щ	
TADI E III		\square	_	_	_	_	+	\perp	-		_	4	+		_	\perp	_	4	-	_		Ш	
TABLE III	_	Nia	20	_	_	_	+	\perp	-		_	+	_		0	_	1	1-	-	-	-		
Output 3	_	Nor	_		_	+	+	+	+		+	+	_		0	1	•		•	•	ŀ		
	_	Rel	ay∣ R Dı	rive	-	+	+	+	+		+	+	+		1 2	_ ՝		_	_		ŀ		
	+				r 20m <i>l</i>		+	+	+		+	+	+		7	_	_	_	•	•	ŀ	Н	
					er Po		Q	nnly	(24)	(dc)	+	+	+		8	١,	_	_	•		ŀ		
+ + +	-	III	ıısır	nue	71 70	wer	ou	ppiy	(24)	/uc)	+	+	+	\vdash	0	+	+	+	┿	Ť	۲		
TABLEIV			\dashv		+	+	+	+	+		+	+	+		\dashv	+	+	+	+	-			
Communications		No	Sele	ecti	on	+	+	+	+	\vdash	+	+	+		0	٠,	,	•	•	•	•		
						eria	L C	omn	าแท่	catio	n	+	+		1	٦,			•	•			
	+											/Ma	nual		2	٦,			•	•		\vdash	
										ote R					-		+		1	1		Н	
		1 1										/	_	-	_	_			-	1	₩	-	
		RS	485	MC	DBL	JS C	om	nmu	nica	tion l					3	- I •	•	· •		•	•		

				Α	vail	abil	ity	
		DC120_						
			¥	¥	¥	1	¥	¥
TABLE V		Selection	1	2	3	4	L	т
Power Supply	Power Supply 90 to 264 Vac	1	•	•	•	•	•	•
	Power Supply 24 to 48 Vac/dc	2	•	•	•	٠	•	•
TABLE VI								H
Manuals	English (51-52-25-123)	0	•	•	•	•	•	•
(Single sheet	French (51-52-25-123-FR)	1	•	•	•	•	•	•
Concise manuals	2	•	•	•	•	•	•	
for UDC1200) Italian (51-52-25-123-IT)		3	•	•	•	•	•	•
	Spanish (51-52-25-123-SP)	4	•	•	•	•	•	•
TABLE VII								
Packaging	Individual Carton	0	•	•	•	•	•	•
	Bulk Pack of 10 identical models	1	•	•	•	•	•	•
	Bulk Pack of 50 identical models	2	•	•	•	•	•	•
	Bulk Pack of 100 identical models 3		•	•	•	•	•	•
TABLE VIII								
Specials	UDC1200 style overlay	0	٠	٠	•	•	•	•
	Special Instrument (Consult Factory)	S						

UDC1200 MICRO-PF	Supplemental		
Universal Digital C	Accessories &	Kits	
Description		Part Number	
Option Slot 1			
Relaymodule		51453391-501	
10 Vdc SSR Driver module		51453391-502	
Linear (mAVdc) module		51453391-504	
Option Slot 2 & 3			
Relay module		51453391-506	
10 Vdc SSR Driver module		51453391-507	
Linear (mAVdc) module		51453391-509	
Dual Relay Board (Slot 2 only)		51453391-510	
24Vdc transmitter module (Slot 3 only)		51453391-511	
Option Slot A			
RS485 communication module		51453391-512	
Digital Input module		51453391-513	
Basic Remote Setpoint module		51453391-515	
Others			
PC Software (includes the cable)		51453391-514	
Product Manual (8 1/2 x 11)	English	51-52-25-122	
	French	51-52-25-122-FR	
UDC1000/1200 Fixing strap		46189016-501	
UDC1500/1700 Fixing strap		46189017-501	
UDC1000/1200 Replacement case		46189018-501	
UDC1500/1700 Replacement case		46189019-501	
DIN Rail Adaptor Kit		46189025-501	

Model Selection Guides are subject to change and are inserted into the specifications as guidance only. Prior to specifying or ordering a model check for the latest revision Model Selection Guides which are published at: http://hpsweb.honeywell.com/Cultures/en-US/Products/Instrumentation/ProductModelSelectionGuides/default.htm

Model Selection Guide

	51-51-16U-85
	Issue 8 Page 1 of 3
	- I get to
MICRO-PRO	Model Selection Guide
l Digital Controller	
key number. The arrow to the right marks the	selections available
in each from Tables I through VIII using the colu	umn below the proper arrow.
1 11 111 117 17 171 1711	VIII
· -	- 1
	1-1
	Selection Availability
Description	
RTD or Linear mV	DC1701 ↓
	DC1702 ↓
·	DC1703 ↓ ↓
	DC1704 ↓
TPSC Controller *	DC170T ↓
Remote Setpoint, Fuzzy Logic, Digital Input *	
* factory set for thermocouple input	
Relay	1 • • • • • •
	2 • • • • •
	3 • • • • •
	4 • • • • •
	5 • • • • •
Linear 4 to 20 mA	7 • • • • •
None	0 • • • •
	1 • • • • •
SSR Driver	2 • • • • •
Linear 0 to 10 Volts	3 • • • • •
Linear 0 to 20 ma	4 • • • • •
Linear 0 to 5 Volts	5 • • • • •
Linear 4 to 20 mA	7 • • • • •
Dual Relay Board	9 •
None	0 • • • •
	1 • • • • •
	2 • • • • •
	3 • • • • •
Linear 0 to 70 voits	4 • • • • •
Linear 0 to 5 Volts	5 • • • • •
Linear 4 to 20 mA	7 • • • • •
Transmitter Power Supply (24Vdc)	8 • • • • • •
	key number. The arrow to the right marks the n each from Tables I through VIII using the column of t

Model Selection Guide (continued)

		DC	170	Αv	ailab	oility	/		L
				¥	\	\	\	¥	¥
TABLE IV		Se	lection	1	2	3	4	Т	R
	No Selection		0	•	•	•	•	•	•
Option 1	RS485 ASCII Serial Communication		1	•	•	•	•		•
	Digital Input (SP1/SP2 Selection)		2	•	•	•	•	•	•
	RS485 MODBUS Communication		3	•	•	•	•	•	•
	Basic Remote Setpoint		4	٠	•	•	•	•	
TABLE V									
Option 2 Power Supply 90 to 264 Vac			1	•	•	•	•	•	•
	Power Supply 24 to 48 Vac/dc		2	•	•	•	•	•	•
TABLE VI				-					
Manuals	English (51-52-25-123)		0	•	•	•	•	•	•
(Single sheet	French (51-52-25-123-FR)		1	•	•	•	•	•	•
Concise manuals	German (51-52-25-123-GE)		2	•	•	•	•	•	•
for UDC1200)	Italian (51-52-25-123-IT)		3	•	•	•	•	•	•
	Spanish (51-52-25-123-SP)		4	•	•	•	•	•	•
TABLE VII									
Packaging	Individual Carton		0	•	•	•	•	•	•
	Bulk Pack of 10 identical models		1	•	•	•	•	•	•
	Bulk Pack of 50 identical models		2	•	•	•	•	•	•
TABLE VIII				_					
Special	None		0	•	•	•	•	•	•
	Special Instrument (Consult Factory)		S						

UDC1700 MICRO-P	Supplemental	
Universal Digital (Accessories & Kits	
Pagarintian		Part Number
Description Option Slot 1		Part Number
Relay module		51453391-501
10 Vdc SSR Driver module		51453391-502
Linear (mAVdc) module		51453391-504
Option Slot 2 & 3		
Relay module		51453391-506
10 Vdc SSR Driver module		51453391-507
Linear (mAVdc) module		51453391-509
Dual Relay Board		51453391-510
24Vdc transmitter module (Slot 3 only)		51453391-511
Option Slot A		
RS485 communication module		51453391-512
Digital Input module		51453391-513
Basic Remote Setpoint module		51453391-515
Option Slot B		
Full remote Setpoint module (to upgrade a I	DC1700 to a DC170R)	51453391-516
Others		
PC Software (includes the cable)		51453391-514
Product Manual (8 1/2 x 11)	English	51-52-25-122
	French	51-52-25-122-FR
UDC1000/1200 Fixing strap		46189016-501
UDC1500/1700 Fixing strap		46189017-501
UDC1000/1200 Replacement case		46189018-501
UDC1500/1700 Replacement case		46189019-501
DIN Rail Adaptor Kit		46189025-501

Warranty/Remedy

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is **in lieu of all other warranties**, **expressed or implied**, **including those of merchantability and fitness for a particular purpose**. Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications are subject to change without notice.

For More Information

Learn more about how Honeywell's UDC1200/1700 Micro-Pro Series can monitor and control temperatures, pressures and levels in a wide range of applications visit our website www.honeywell.com/ps/hfs or contact your Honeywell account manager.



Honeywell Process Solutions

1860 W. Rose Garden Lane Phoenix, Arizona 85027

Tel: 1-800-423-9883 or 1-800-343-0228

www.honeywell.com/ps



51-52-03-35 June 2011 © 2011 Honeywell International Inc.