Honeywell

51-51-16U-80 Issue 17 Page 1 of 3

UDC3200 Universal Digital Controller

Model Selection Guide

New! Easy To Use UDC3200 1/4 DIN Single Loop Controller

- The UDC3200 Controller packs new powerful features while retaining all the simplicity and flexibility of the industry standard UDC3300 Controller. Many new optional features include: - Enhanced Display

 - Built-in infrared communications port for configuring with a Pocket PC or Laptop
 - PC Based Configuration Tools
 - Ethernet Communications
 - Two Analog Inputs
 - Accutune III, Fast/Slow, Heat/Cool
 - Thermocouple Health Monitoring

Instructions

Select the desired key number. The arrow to the right marks the selection available. Make the desired selections from Tables I through VI using the column below the A dot (•) denotes availability. proper arrow. Key Number н VI ___ ____



UDC3200 Controller

•

•

•

•

•

•

•

• •

•

•

•

• •

KEY NUMBER - UDC3200 Single Loop Controller	_			If Applicable
Description	Selection	Availab	oility	Stocking P/N
Digital Controller for use with 90 to 250Vac Power	DC3200	+		
Digital Controller for use with 24Vac/dc Power	DC3201		↓	

TABLE I - Specify Control Output and/or Alarms

	Current Output (4 to 20ma, 0 to 20 ma)	ſ	C _
	Electro Mechanical Relay (5 Amp Form C)		Ε_
Output #1	Solid State Relay (1 Amp)		Α_
	Open Collector transistor output		Τ_
	Dual 2 Amp Relays (Both are Form A) (Heat/Cool Applications)		R_
	No Additional Outputs or Alarms	ſ	_ 0
Output #2 and Alarm	One Alarm Relay Only		_ B
#1 or Alarms 1 and 2	E-M Relay (5 Amp Form C) Plus Alarm 1 (5 Amp Form C Relay)		_E
	Solid State Relay (1 Amp) Plus Alarm 1 (5 Amp Form C Relay)		_ A
	Open Collector Plus Alarm 1 (5 Amp Form C Relay)		_ T

TABLE II - Communications and Software Selections

	None	0	•	•	
Communications	Auxiliary Output/Digital Inputs (1 Aux and 1 DI or 2 DI)	1	•	٠	
Communications	RS-485 Modbus Plus Auxiliary Output/Digital Inputs	2	•	•	
	10 Base-T Ethernet (Modbus RTU) Plus Auxiliary Output/Digital Inputs	3	•	•	
	Standard Functions, Includes Accutune	_0	•	•	
Software Selections	Math Option	_A	•	•	
Soltware Selections	Set Point Programming (1 Program, 12 Segments)	_B	•	•	
	Set Point Programming Plus Math	_C	•	•	
Reserved	No Selection	0_	•	•	
Infrared interface	Infrared Interface Included (Can be used with a Pocket PC)	R	•	•	

TABLE III - Input 1 can be changed in the field using external resistors	
The set of	

Input 1	TC, RTD, mV, 0-5V, 1-5V TC, RTD, mV, 0-5V, 1-5V, 0-20mA, 4-20mA TC, RTD, mV, 0-5V, 1-5V, 0-20mA, 4-20mA, 0-10V
Input 2	None TC, RTD, mV, 0-5V, 1-5V, 0-20mA, 4-20mA TC, RTD, mV, 0-5V, 1-5V, 0-20mA, 4-20mA, 0-10V Slidewire Input for Position Proportional (Requires 2 Relay Outputs) Carbon, Oxygen or Dewpoint (Provides 2 Inputs)

DC	3200	3201	If Applicable
Selection	¥	→	Stocking P/N
1	•	٠	
2	•	•	
3	•	•	
_ 00	٠	•	
_ 10	•	•	
_ 20	•	•	
_ 40	а	а	
60	b	b	

•

٠

•

•

٠

•

•

•

•

Availability

0

0___

0

0

٠

٠

0

0 •

Т

TABLE IV - Options

Approvals	CE (Standard) CE, UL and CSA
Tags	None
Tays	Stainless Steel Customer ID Tag - 3 lines w/22 characters/line
	None
Future Options	None
	None

TABLE V - Product Manuals

	Product Information on CD - All Languages	0_	Γ
	English Manual	Ε_	
Manuals	French Manual	F_	
iviariuais	German Manual	G_	
	Italian Manual	Ι_	I
	Spanish Manual	S_	
Certificate	None	_ 0	T
Certificate	Certificate of Conformance (F3391)	_C	

0 _ E _ F _ G _ I _ S _	•	•	
_ 0	•	•	
_ C	•	•	

TABLE VI

No Selection None

ORDERING INSTRUCTIONS: These are provide as guidance for ordering such as those listed

- 1. Part numbers are provided to facilitate Distributor Stock.
- 2. Orders may be placed either by model selection or by part number.
- 3. Part numbers are shown within the model selection tables to assist with compatibility information.
- 4. Orders placed by model selection are systematically protected against incompatibility.
- 5. Compatibility assessment is the responsibility of the purchaser for orders placed by part number.
- 6. Items labeled as N/A are not available via the stocking program and must be ordered by model selection.

RESTRICTIONS

Restriction Letters	Availa	ble Only With		Not Available With
	Table	Selection	Table	Selection
	I	EE		
а	I	AA		
	I	R_		
b		1		

Honeywell

UDC3200 Universal Digital Controller

Supplemental Accessories & Kits

Description	Part Number			
Bezel Assembly and Bezel Gasket	51453143-502			
Display/Keyboard (with IR)		51452845-501		
Power/Output PWA with 2 E-M Relays (90-264 Vac O	peration)	51452822-502		
Power/Output PWA with 2 E-M Relays (24 Vac/dc Ope	eration)	51452822-503		
Optional Analog Input PWA		51452825-501		
Auxiliary Output/Digital Input/RS-422/485 Communica	tions PWA	51452810-501		
Auxiliary Output/Digital Input/Ethernet Communication	is PWA	51452816-501		
MCU/Inputs PWA		51452819-501		
Electro-Mechanical Relay		30755306-501		
Open Collector Output PWA		30756679-501		
Solid State Relay		30756725-501		
Current Output PWA		51452804-501		
Dual Electromechanical Relay PWA		51452807-501		
Ethernet Adaptor Board Kit		50009071-501		
Case Assembly (including Mounting Kit with four brack	kets)	51452759-501		
Varistor (MOV) 120 Vac		30732481-501		
Varistor (MOV) 240 Vac		30732481-502		
4-20 mA Input Resistor Assembly (250 ohm)		30731996-506		
0-10 Volt Input Resistor Assembly (100K pair)		30754465-501		
Mounting Kits (12 Brackets)		51452763-501		
DIN Adaptor Kit		30755223-003		
Process Instrument Explorer Software		50001619-001		
Math Software Upgrade	50004635-501			
SPP Software Upgrade	50004635-502			
Panel Bracket Kit	50004821-501			
Product Information on CD	Product Information on CD All Languages			
Quick Start Manual (2 page) Standard	Quick Start Manual (2 page) Standard English			
Product Manual	51-52-25-119			

Distributed by:



Relevant Solutions | 888-858-3647 | relevant solutions.com